

# LAMBRIGHT THEATER SEAT MOUNTING

## STEP 1: DETERMINE YOUR SLIDEOUT TYPE

If no slide, then mount like **#1 Flush Slide**. We do not recommend mounting on *Raised Short Slideouts* more than 3.5" high. Our rollers will accommodate *Short Raised Slideouts* ranging from 2"- 3.5" high.



### #1 RAISED SHORT SLIDE

Always raised – in or out  
Typically 2"-6" high  
18"-29" deep

**Rollers needed – see roller install pdf**



### #2 RAISED DEEP SLIDE

Always raised – in or out  
Typically 2"-6" high  
30"-44" deep

**No rollers needed**



### #3 FLUSH SLIDE

Slide goes out and drops down almost level with main floor  
Typically 2" high (when in)  
24"-46" deep

**No rollers needed**

## STEP 2: POSITION PROPERLY FOR MOUNTING

If mounting on #1 Raised Short Slide. Please see separate roller install pdf.



STEP A



STEP B



STEP C



STEP D

- (A) Place seat base on slide if you have a **#1 Raised Short Slideout** (shown), place wood blocks under front of frame to level  
(B) Loosely attach back frame, recline all the way (We recommend pushing down on seat bottom when reclining for correct positioning.) and reposition if necessary so back is 1/2" from wall (C) (when reclined).  
(D) Back of recliner should sit 3.5" to 4" from wall when in upright position depending on model (Venture model sits .5" from wall)

## STEP 3: SECURE TO FLOOR (Screw into floor thru frame with wood screws and washers or use C clamps.)



USE THESE HOLES ON FRAME IF NOT USING CLAMPS

### OPTION 1 WOOD – MOST TYPICAL

Screw to floor with 1.25" wood screws and washers thru frame (shown left)

### OPTION 2 METAL PLATE IN FLOOR

Use 1.25" self-tapping screws (shown left)


### OPTION 3 CLAMPS

Clamps can be used with wood screws, metal self-tappers, lag bolts, and elevator bolts (shown right)

All parts are available on our website.



WOOD SCREWS  
SELF-TAPPING SCREW  
ELEVATOR BOLT



FOR TILE FLOORS, DRILL THROUGH THE GROUT, NOT THE TILE

Clamps make it easier to install, providing a better angle for screw gun; also a must for tile floor on slideouts. Elevator bolt thru slide for extreme holding power.

